

FIG. 2A




FIG. 2B




FIG. 3

I. NVPA (NEUROVASCULAR)

- QUADRATURE / PHASED ARRAY MODE
- CONFIGURATION FILE WILL TURN ON ENTIRE ARRAY
- MAY BE USED FOR ALL TYPE OF BRAIN AND NECK IMAGING, EXCLUDING ECHO PLANAR IMAGING (EPI)
- FOV 46CM (MAXIMUM)

RECOMMENDED USES:

- BRAIN AND OR CERVICAL SPINE LOCALIZERS
- IMAGING OF THE CERVICAL SPINE
- IMAGING OF THE CAROTID ARTERIES
- IMAGING OF THE AORTIC ARCH




FIG. 4

2. FASTBRN (FAST BRAIN)

- QUADRATURE MODE
- CONFIGURATION FILE WILL TURN ON ONLY THE HEAD COIL SECTION OF THE ARRAY
- MAY BE USED FOR ECHO PLANAR IMAGING (EPI)
- MAY BE USED FOR VASCULAR STUDIES OF THE BRAIN TO REDUCE RECON TIME
- FOV 24 CM

RECOMMENDED USES:

- EPI SEQUENCES
- IMAGING OF THE BRAIN
- IMAGING OF CIRCLE OF WILLIS




FIG. 5

3. HRBRN (HIGH RESOLUTION BRAIN ARRAY)

- QUADRATURE/PHASED ARRAY MODE
- CONFIGURATION FILE WILL TURN ON ONLY THE HEAD COIL SECTION OF THE ARRAY
- USE CONFIGURATION WHEN IMAGING THE BRAIN FOR HIGH RESOLUTION
- COMPATIBLE WITH ALL IMAGING SEQUENCES, EXCEPT EPI
- FOV 24 CM

RECOMMENDED USES:

- HIGH RESOLUTION BRAIN IMAGING
- HIGH RESOLUTION CIRCLE OF WILLIS IMAGING

